

Updating the FEMU Firmware

1. Download the proper firmware revision & unzip the downloaded file.
2. Copy FEMU.BIN and FIRMWARE.XVF files to the SD card.
3. Insert SD Card into FEMU and turn ON
4. Hold down the PREV and NEXT buttons while you press and release the RESET button. Continue to hold down the PREV and NEXT buttons until you see “Updating CPLD” – you can then release the PREV and NEXT buttons.
5. Status light should be blinking to show that it is working.
6. When you see RESULT SUCCESS Step 1 is completed.
7. You may get a WRONG CPLD error message. This is normal.
8. Hold down the PREV and SELECT buttons while you press and release the RESET button. The second component FEMU.BIN starts to install. Status light will flash to show its working. When you see the FLOPPY EMU menu on the screen, the firmware update is completed.

Source: Steve Chamberlain’s YouTube video at:

<https://www.youtube.com/watch?v=GqpngugO1U>

Floppy EMU Support Online:

<https://www.bigmessowires.com/contact/#products>